Little Giant®
Little Giant
P. O. Box 12010
Oklahoma City, OK 73157-2010
405.947.2511 • Fax: 405.947.8720
www.LittleGiant.com
customerservice@lgpc.com

VILLAGE PUMP PLANTER FOUNTAIN

MODEL FP-VPPF

READ INSTRUCTIONS CAREFULLY BEFORE ATTEMPTING TO INSTALL, OPERATE OR SERVICE THE LITTLE GIANT PUMP. KNOW THE PUMP APPLICATION, LIMITATIONS, AND POTENTIAL HAZARDS. PROTECT YOURSELF AND OTHERS BY OBSERVING ALL SAFETY INFORMATION. FAILURE TO COMPLY WITH INSTRUCTIONS COULD RESULT IN PERSONAL INJURY AND/OR PROPERTY DAMAGE! RETAIN INSTRUCTIONS FOR FUTURE REFERENCE.

SAFETY GUIDELINES

⚠WARNING⚠

1. Make certain that the unit is disconnected from the power source before attempting to service or remove any component.
2. Do not use to pump flammable or explosive fluids such as gasoline, fuel oil, kerosene, etc. Do not use in explosive atmospheres. Pump should only be used with liquids compatible with pump component materials.
3. Do not handle pump with wet hands or when standing on a wet or damp surface or in water.
4. This pump is supplied with a grounding conductor and/or grounding type attachment plug. To reduce the risk of electric shock be certain that it is connected to a properly grounded grounding type receptacle.
5. The National Electric Code (in the USA) and similar codes in other countries require a Ground Fault Circuit Interrupter (GFCI) to be installed in the branch circuit supplying fountain equipment rated above 15 volts. Little Giant recommends that each pump be used with a GFCI.
6. Do not allow children or infants to play near the fountain due to drowning hazard.

ASSEMBLY INSTRUCTIONS

1. Remove fountain assembly, fountain components, and all packaging from carton and place on a smooth flat surface.
2. Place pump into basin and fill with water until pump is submerged by approximately 1". Do not route the power cord through the cone shaped hole at this time. Remove pump from basin.
3. Locate flexible tubing on bottom of ornamental pump and connect to pump discharge.
4. Route the pump power cord through the cone shaped hole inside the basin and align with the recess on the bottom of the basin.
5. With water pump hanging from ornamental pump, carefully lower pump into basin, ensuring that the pump stands on the four suction cups mounted to the bottom of the pump.
6. Secure the ornamental pump to the basin with the two lag screws provided. **DO NOT OVER-TIGHTEN.**
7. Plug pump into GFCI outlet. Note that water can be added to the top basin reservoir or pump flow can be reduced to achieve desired effect. To reduce pump flow, simply turn the dial on the inlet of the pump in a clockwise direction.

ELECTRICAL CONNECTIONS

⚠WARNING⚠

1. Check the pump label for proper voltage required. Do not connect to voltage other than that shown.
2. If pump is supplied with a 3-prong electrical plug, the third prong is to ground the pump to prevent possible electrical shock hazard. **DO NOT REMOVE** the third prong from the plug. A separate branch circuit is recommended. Do not use an extension cord. Do not cut plug from the cord. If the plug is cut or the cord is shortened, then this action will void the warranty.
3. There is an adjustment on the pump to regulate the flow of water.

MAINTENTANCE

- Do not allow the pump to run without water or allow to freeze.
- Clean fountain out only with water and, if desired, use only a tablespoon of chlorine to prevent algae. **DO NOT USE BLEACH.** It may tarnish the applied finish.

TROUBLESHOOTING

PROBLEM	CORRECTIVE ACTION
Pump is not working.	Check power outlet. Refer to manufacturer's instructions.
Pump is working but water is not flowing.	Check for kinks in the tube. Make sure pump is submerged. Make sure pump is free of debris.

WARRANTY

One year limited warranty from date of purchase. Contact the manufacturer for all warranty details.

For Parts or Repair, please contact. 1.888.572.9933
For Technical Assistance, please contact. 1.888.956.0000

www.LittleGiant.com
customerservice@lgpc.com

©Copyright 2006 Little Giant
Form 14940414 — 02/2006
Little Giant Print Services